
UNIT 'A' - MAIN CONTROL PANEL
UNIT 'B' - CRASH FREQUENCY CONTROL PANEL (PS-16 MODEL-15)
UNIT 'P' TEL. CABINET
UNIT 'C' - ELECTRONIC MIXER (PS-16 MODEL-15B)
UNIT 'D' C.O.D. AMPLIFIER UNIT
UNIT 'E' - LIMITING AMPLIFIER NO. 1 (PS-16 MODEL-11)
UNIT 'F' LIMITING AMPLIFIER NO. 2 (WIRING DIAGRAM THE SAME AS LIMITING AMPLIFIER #1)
UNIT 'G' - RECORDER UNIT (MODEL PE)
UNIT 'H' - RECORDER UNIT (MODEL PE)
UNIT 'I' - RECORDER UNIT (MODEL PE)
UNIT 'J' - RECORDER UNIT (MODEL PE)
REC #1 (5105 KC)
REC #2 (3235 KC)
REC #3 (3385 KC)
REC #4 (6465 KC)
REC #5 (5105 KC)
REC #6 (3235 KC)
REC #7 (3385 KC)
REC #8 (6465 KC)
REMOTE RECVR #1
REMOTE RECVR #2
REMOTE RECVR SWITCHING PANEL (TAB. #1 & 2 SHOWN)
LOCAL RECVR NO. 1
C.O.D. RELAY AMPLIFIER
ELECTRONIC MIXER
SCHEMATIC DIAGRAM SHOWING CONNECTIONS FOR TRANSFER OF CONTROL FROM LOCAL TO REMOTE RECEIVERS.
NOTES:
1. J1 IS A 61 CONTACT AMPHENOL SOCKET, J2 IS A 61 CONTACT AMPHENOL SOCKET, J3 IS A 12 CONTACT FEMALE CANNON CONNECTOR, J4 IS A 12 CONTACT MALE CANNON CONNECTOR, J5 IS A 61 CONTACT AMPHENOL SOCKET, J6 IS A 61 CONTACT AMPHENOL SOCKET, J7 & J8 ARE 6 CONTACT CANNON CONNECTORS ALL IN PARALLEL TO CONTROL PANEL. P1, P2, P3, P4, P5, P6, P7, P8, P9, P10, P11, P12, P13, P14, P15, P16 ARE RESPECTIVE PLUGS.
2. J9 & J10 ARE 6 CONTACT CANNON CONNECTORS IN PARALLEL TO J1 & J2 RESPECTIVELY. P17 & P18 ARE RESPECTIVE PLUGS.
3. J11 & J12 ARE 6 CONTACT AMPHENOL SOCKETS IN BACK OF LIMITING AMPLIFIERS. P19 & P20 ARE RESPECTIVE PLUGS.
4. J13, J14, J15, J16 AND J17 ARE 48 CONTACT CANNON CONNECTORS MOUNTED IN REAR OF RECS. 1, 2, 3, & 4 RESPECTIVELY. P21, P22, P23, P24, & P25 ARE RESPECTIVE CONNECTOR PLUGS.
5. AUDIO & REL OUTPUT TAPS ON RECEIVERS ARE NOT SHOWN. SEE PROPER REFERENCE DRAWINGS FOR TAPS ON EACH RECEIVER USED.
ALTERATIONS
REFERENCE DRAWINGS
RADIO MATERIAL OFFICE
NAS AND NOAS
AIRPORT TRAFFIC CONTROL TOWER RADIO COMMUNICATIONS CONTROL SYSTEM
SCHEMATIC WIRING DIAGRAM
RS 432 5320